


School Bell Timer + Multi Event Timer



**Product Overview:**

- TimeLine Multi is an Event Based pre-settable timer in which user can feed the schedule at once and it will control the load as per the schedule and given time.
- Developed mainly for:
  - **School Bell ON/OFF** in pre-scheduled manner and at accurate time with taking care of holidays.
  - **Factory sirens, Office Tea time/Lunch time Bells** control in pre-scheduled manner.
  - **Water Irrigation System (Sprinkler)** control in pre-scheduled manner.
  - **Home Appliance control** at pre-scheduled time mainly for:
    - Water Heater, Geyser.
    - Washing Machine.
    - Air Conditioner (AC) Control.

<u>Salient Features</u>	<u>Specifications</u>
<ul style="list-style-type: none"> <li>• 16x2 LCD display and 3 Keys for user</li> <li>• Max. 30 Programmable events per day.</li> <li>• Weekdays setting for each event.</li> <li>• 20 user programmable holiday dates.</li> <li>• 10 user programmable holiday date ranges.</li> <li>• Programmable event ON time duration.</li> <li>• <i>Bypass mode</i> for manual operation.</li> <li>• Timer Modes: 1.School Bell timer 2.Multi Event Timer</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Supply Voltage:</b> 130V-350V AC/50Hz</li> <li>• <b>Output Contact ratings:</b> 5 KW at 230V</li> <li>• <b>Dimensions:</b> 73 (H) x 118(V) x 63(D)</li> <li>• <b>Compliant To the following IEC standards:</b> <ul style="list-style-type: none"> <li>IEC 61000-4-4</li> <li>IEC 61000-4-5</li> <li>IEC 61000-4-11</li> <li>IEC 61000-4-14</li> <li>IEC 61000-4-28</li> </ul> </li> </ul>

**Note:** The only difference in School bell mode is that Bypass mode keeps the load ON only for 15 seconds, as to avoid the school bell ringing continuously and getting damaged.



**Operating Instructions:**

**1. Current Date and time settings**

Step	Operation	Key	Display
1	To Select date and time edit settings	Press (MENU+UP+EDIT) for 2 seconds	'Date' field of current date blinks(DD:MM:YY)
2	To change the value of blinking field	Press UP key	Value corresponding to blinking field increases
3	To move the cursor to next field	Press EDIT Key	Next field blinks
4	To save and exits Current date/time settings	Press EDIT key till blinking cursor is at the last field and press EDIT key one more time	'SETTINGS SAVED' message flashes

**\*Note: If settings are left incomplete (no key is pressed for 10 seconds), whatever setting done so far will automatically get saved after 10 seconds and setting mode exits.**

**2. Select Bypass Mode (Manual ON/OFF ) For Multi Event Timer**

Step	Operation	Key	Display
1	To Select Bypass Mode	Press and hold (MENU+UP) keys for 2 seconds.	'BYPASS MODE' is displayed
2	To exit from Bypass Mode	Press and hold (MENU+UP) keys for 2 seconds.	Default display as 'HH:MM:SS', 'DD/MM/YY [DAY]'

**\*Note: Bypass mode is used for manually turning ON or OFF the load.**

**3. Select Bypass Mode (To Manually Ring the Bell ) For School Bell Timer**

Step	Operation	Key	Display
1	To Select Bypass Mode	Press and hold (MENU+UP) key for 2 seconds.	'BYPASS MODE' is displayed

**\*Note: Bypass Mode Will Only keep the Bell ON for 15 seconds after that it will automatically OFF.**




4. To VIEW/EDIT events

Step	Operation	Key	Display
1	To enter main menu	Press MENU key for 2 seconds	' MENU: '> VIEW/EDIT'
2	To scroll menu items	Press UP key	' MENU: '> HOLIDAY RANGE'
3	Next menu item	Press UP key	' MENU: '> HOLIDAY'

Pressing 'UP' key shows next menu item in the list

3	To enter VIEW/EDIT event settings	Press EDIT key when 'VIEW/EDIT' option is onscreen	'#01   AT            HH:MM' 'OFF  FOR HH:MM:YY'  And  'S M T W T F S ' 'X V X V X V V '  Alternately
---	-----------------------------------	--	---

Settings of Event No. 1 are shown on Display. This is VIEW mode.



4	To view next event in the list	Press UP key	'#02   AT            HH:MM' 'OFF  FOR HH:MM:SS'  And  'S M T W T F S ' 'X V X V X V V '  Alternately
---	--------------------------------	--------------	---

\*Event which is currently being displayed can be edited right there by pressing 'EDIT' key

5	To edit event currently	Press EDIT key	'OFF' field of blinks.
---	-------------------------	----------------	------------------------




6	To change the value of blinking field	Press UP key	Value of blinking field changes
7	To move to next field	Press EDIT key	Next field blinks
<p><b>*Similarly, all fields can be edited. After duration is set, weekdays settings for the same event is displayed</b>                  ' S   M   T   W   T   F   S   '                  ' x   x   x   x   x   x   x   '                  First Cross mark of Sunday blinks.</p>			
8	To change the value of blinking field ( X or V )	Press UP key	Value of blinking field changes
9	To move to next Field	Press EDIT key	Next field blinks
<p>Once all days are set, 'CHANGES SAVED' message is displayed and control is back to 'VIEW' Mode with display as:</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;">XX - Event No.</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">                     '#XX   AT            HH:MM'                      'OFF   FOR   HH:MM:YY'                      And                      ' S   M   T   W   T   F   S   '                      X V X   V X   V V                   </div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> <div style="margin-left: 20px;">←</div> </div> <p style="text-align: right; margin-right: 50px;">Alternately</p> <p>Now, you can use UP key to VIEW event                  Also, Pressing 'MENU' button anywhere in the Menu takes the settings one step back by automatically saving the current changes.</p>			
10	To exit from VIEW/EDIT option	Press MENU key.	' MENU: ' ' > VIEW/EDIT '
11	To exit from the menu	Press MENU key again.	' HH:MM:SS ' ' DD/MM/YY [DAY] '
<p style="text-align: center;">Default display contents are                  ' HH:MM:SS '                  ' DD/MM/YY [DAY] '                  Also, upcoming event is shown alternately for 4 seconds.</p>			



5. View/edit Holiday Range Settings

Step	Operation	Key	Display
1	To enter main menu	Press MENU key for 2 seconds	' MENU: , > VIEW/EDIT ,
2	To scroll menu items	Press UP key	' MENU: , > HOLIDAY RANGE '
3	To enter 'HOLIDAY RANGE' settings	Press EDIT key	'#01  FRM DD/MM/YY' 'OFF  TO DD/MM/YY'



4	To view next holiday in the list	Press UP key	'#02  FRM DD/MM/YY' 'OFF  TO DD/MM/YY'
<b>*Holiday range which is currently being displayed can be edited right there by pressing 'EDIT' key</b>			
5	To edit holiday info currently displayed on LCD	Press EDIT key	Date field of start date blinks
6	To change the value of blinking field	Press UP key	Value of blinking field changes
7	To move to the next field	Press EDIT key	Next field blinks
<b>*Similarly, all fields can be edited. After last field is set by pressing NEXT key, changes are saved and control is back to VIEW mode.</b>			
8	To exit from holiday settings	Press MENU key	'MENU: > HOLIDAY RANGE ,
9	To exit from the menu	Press MENU key again	'HH:MM:SS , 'DD/MM/YY [DAY] ,


**\*Note:**

- Pressing MENU button anywhere in the Menu takes the settings one step back by automatically saving the current changes.
- If settings are left incomplete (No key is pressed for 2 minutes), whatever setting done so far will automatically get saved after 2 minutes and setting mode exits.

6. View /Edit Holiday Settings



Step	Operation	Key	Display
1	To enter main menu	Press MENU key for 2 seconds	' MENU: , > VIEW/EDIT ,
2	To scroll menu items	Press UP key	' MENU: , > HOLIDAY ,
3	To enter 'HOLIDAY' settings	Press EDIT key	'HOLIDAYS: , '#01 DD/MM/YY [x] ,



Step	Operation	Key	Display
4	To view next holiday in the list	Press UP key	'HOLIDAYS:' '#02 DD/MM/YY [x] ,
<b>*Holiday info which is currently being displayed can be edited right there by pressing 'EDIT' key</b>			
5	To edit holiday info currently displayed on LCD	Press EDIT key	Date field blinks
6	To change the value of blinking field	Press UP key	Value of blinking field changes
7	To move to the next field	Press EDIT key	Next field blinks
<b>*Similarly, all fields can be edited. After last field (cross/tick) is set, changes are saved and control is back to VIEW mode.</b>			
8	To exit from holiday settings	Press MENU key.	'MENU:' '> HOLIDAY'
9	To exit from the menu	Press MENU key again.	Default display as 'HH:MM:SS' 'DD/MM/YY [DAY]'

- \*Note:**
- Pressing MENU button anywhere in the Menu takes the settings one step back by automatically saving the current changes.
  - If settings are left incomplete (No key is pressed for 2 minutes), whatever setting done so far will automatically get saved after 2 minutes and setting mode exits.




**7. To Select Timer Mode: School Bell Timer / Multi Event Timer**

Step	Operation	Key	Display
1	To Select School Bell Mode	Press and hold (UP Key) for 6 seconds.	"Timer Mode: School Bell " is displayed
2	To Select Multi Event Mode	Press and hold (UP Key) for 6 seconds.	"Timer Mode: Multi Event" is displayed

**Wiring Guide:**

- Terminal Connections For Single phase load up To 4 kw



- Terminal Connection For 3 Phase Load

